

# Montage Doppelfadenkopf

## Motorsense CG260T / CG330T / CG430T

*Schritt 1:*



*Schritt 2:*



*Schritt 3 (Wickelschutz)*



*Schritt 4:*



# Montage 3 Zahnblatt

## Motorsense CG260T / CG330T / CG430T

*Schritt 1:*



*Schritt 2:*



*Schritt 3:*

